

# KYOCERA

## **Bluetooth Power**

Ensure Bluetooth is turned ON permanently.

## **Discoverable/Visible**

1. Go to **Menu**
2. Select **Bluetooth**
3. Set to **Visible**

## **Auto Answer**

1. Go to **Menu**
2. Select **Settings**
3. Select **Accessories**
4. Set *Auto Answer* to DISABLED