

SANYO

Bluetooth Power

Ensure Bluetooth is turned ON permanently.

Discoverable/Visible

1. Go to **Menu**
2. Select **Settings**
3. Select **Bluetooth**
4. Set *Visibility* to Always Visible

Authorize Connection

1. Go to **Menu**
2. Select **Settings**
3. Select **Bluetooth**
4. Select **Permissions**
5. Set *Handsfree* to Always Allow

Auto Answer

1. Go to **Menu**
2. Select **Settings**
3. Select **Others**
4. Select **Auto Answer**
5. Set *Handsfree* to OFF

Answer Options

1. Go to **Menu**
2. Select **Settings**
3. Select **Others**
4. Select **Open/Close Flip** or **Any Key Answer**